

(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions


(IT) Istruzioni di montaggio

(PL) Instrukcja montażu

(SK) Návod na montáž




(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба	
Name • Nom • Nome • Naam Nazwa • Jméno • Назов • Név Denumire • Isim • Название	
Nr • No. • N° • Номер • Č • Sz	4694 2618
Typ • Type • Tip • Típus • Тіро Тип	





X8





X1

A 8F	B M8X60	C 5A	D M3.5	E M2
X16	X16	X1	X1	X16





1



2

A	8F	B	M8X60	C	5A	D	M3.5	E	M2
	X16		X16		X1		X1		X16



3

