






<p><b>Ax1</b></p> 		<p><b>Bx1</b></p> 	<p><b>Cx4</b></p> 	<p><b>Dx8</b></p>  <p>M6X14MM</p>
<p><b>Ex4</b></p>  <p>M6X25MM</p>	<p><b>Fx4</b></p>  <p>M6X16X1MM</p>	<p><b>Gx1</b></p> 		



- (D)** Bitte überprüfen Sie in regelmäßigen Abständen den festen Sitz der Schrauben!
- (GB)** Please check the screws for tightness at regular intervals!
- (F)** Veuillez contrôler régulièrement que les vis sont convenablement serrées !
- (ES)** ¡Compruebe periódicamente que los tornillos estén bien apretados!
- (IT)** Controllare regolarmente che le viti siano ben strette!
- (PL)** Należy regularnie sprawdzać dokręcenie śrub!
- (NL)** Controleer op regelmatige afstanden of de schroeven goed vast zitten.
- (SWE)** Kontrollera med jämna mellanrum att skruvarna sitter fast ordentligt!
- (SK)** V pravidelných intervaloch kontrolujte pevné dotiahnutie skrutiek!
- (SL)** Redno preverjajte, ali so vijaki trdno priviti!
- (HR)** Redovito provjeravajte čvrsto nalijeganje vijaka!