SINCE 1908

SOLIS Flex Toaster

Individually adjustable toaster with 7 programs for different types of bread and pastries, 4 freely programmable memory locations, countdown timer and much more.



7 different bread types

7 individual programs for different types of bread: White or whole wheat breads, bagels, waffles, English muffins, braid and gluten-free bread.



Memory function

4 freely programmable memory locations eliminate the need to repeatedly enter your preferred settings.



Suitable for gluten-free bread A special function with shortened toasting time browns even gluten-free bread evenly.

Features

- + Centring mechanism for toast slices
- + The super-wide toast slots brown toast slices, bagels or English muffins up to a size of 12 x 13.5 cm.
- + Easy to empty crumb tray
- + Large backlit LCD display



Defrost & reheat function Simply defrost frozen pastries or quickly reheat toast or bread for ultimate convenience and optimal taste.

Type 8004

Count-down timer

The count-down timer displays the remaining duration of the selected operation.

C DISANTE CANA 2 BAOL SMEET 2 BAOL SMEET 2 BAOL SMEET 1 DISANTHA

Detachable bun warmer The solid warming rack with heat-insulated handles warms up buns, croissants and much more.

Specifications

Article no.:	920.15
Material:	stainless steel
Output:	800 - 950 W
Weight:	1.4 kg (without bun warmer)
Dimensions:	18 x 27 x 19 cm
	(w x d x h)
EAN:	7611210920151











So Swiss, so Solis.